



## FOOT LOCK



9223  
Foot Lock



9224  
Foot Lock  
Keeper Standard  
(Alum.)



9225  
Foot Lock  
Keeper Recessed/Flush  
(S/S)

## SAFE & SECURE

The Foot lock lets you easily lock the Slidetek Frameless Glass Door panels in place by pushing down on top of the Footlock with your foot. The easy to use Footlock has been designed to easily get your foot under the lock when you're ready to unlock and slide the doors back again.

